

Maintenance

WARNING

Before beginning maintenance, be sure to turn "OFF" the power ON/OFF switch, and remove the power plug from the socket. Otherwise, you might receive an electric shock or be injured.

- 1** Open the suction port door.
* The door is fixed with a magnet.



- 2** Lock the door in an open state.

● Fully insert the lock pin.




Caution

Fully insert the lock pin into the hole at the bottom inside the door.

- 3** Remove the pre-filter, and evacuate dust and dirt adhering to the filter, using a vacuum cleaner.

● Remove the pre-filter.



● Evacuate dust and dirt using a vacuum cleaner



- 4** Install the pre-filter and the lock pin back in place, and close the suction port.

* When the equipment is operated after the pre-filter has been cleaned, the equipment might sputter; however, this is not a failure.

